







| TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES |  |                        |          |             |  |
|--------------------------------------------------------|--|------------------------|----------|-------------|--|
| Verdichter/Compressor/Compresseur                      |  | Bosch                  |          | Danfoss     |  |
| Typ/Type                                               |  | V 1040                 |          | TL 5 A      |  |
| Förderleistung/Delivery/Débit                          |  | l/h                    |          | V 920       |  |
| Anlaufstrom/Starting current/Cour. de démarrage        |  | A                      |          | 9,0         |  |
| Widerstand/Resistance/Résistance                       |  | Ha/main/prin. $\Omega$ |          | 15,7        |  |
|                                                        |  | Hi/aux $\Omega$        |          | 18,8        |  |
| Temp.-Regler/Thermostat                                |  | Bosch                  |          |             |  |
| Typ/Type                                               |  | kalt    warm           |          |             |  |
| Reglerstellung/Position                                |  | $^{\circ}\text{C}$     |          |             |  |
| Schaltwerte/Switching values/                          |  | „ein“                  |          | - 25   - 19 |  |
| Valeurs de commutation                                 |  | „aus“                  |          | - 33   - 26 |  |
|                                                        |  | („abtauen“ od.)        |          | - 20   - 15 |  |
| Füllmenge/Fill.quantity/Charge                         |  | R12                    | g        | 210         |  |
| Anschlußwert/Conn.load/Puiss. connectée                |  |                        | W        | 120         |  |
| Heizung/Heater/Chauffage                               |  |                        |          |             |  |
| Widerstand/Resistance/Résistance                       |  |                        | $\Omega$ |             |  |
| Leistung/Power/Puissance                               |  |                        | W        |             |  |
| Ventilator/Blower/Ventilateur                          |  |                        |          |             |  |
| Widerstand/Resistance/Résistance                       |  |                        | $\Omega$ |             |  |
| Magnetventil/Magnetic valve/Electrovanne               |  |                        |          |             |  |
| Widerstand/Resistance/Résistance                       |  |                        | $\Omega$ |             |  |
| Spannung/Voltage/Tension                               |  |                        | V        |             |  |

| Pos. | bis FD 621 | ab FD 622  |               |  |
|------|------------|------------|---------------|--|
|      | Bosch      | Bosch      | Danfoss       |  |
| 1    |            |            | 14 0065/45    |  |
| 2    | 07 2131/18 |            |               |  |
| 3    | 07 2130/18 | 07 3899/09 | 02 0108/27    |  |
| 4    | 04 9865/05 |            |               |  |
| 5    |            |            |               |  |
| 6    | 04 9865/05 |            | 05 1413/05    |  |
| 7    |            |            |               |  |
| 8    |            |            | *11 1919/04   |  |
| 9    | 01 4895/02 |            | 05 0166/05    |  |
| 10   |            |            |               |  |
| 11   |            |            |               |  |
| 12   |            |            |               |  |
| 13   |            |            | *04 1568/01/2 |  |
| 14   |            |            | *05 1226/08   |  |

\*) Bei Ersatz des Bosch-Verdichters mitbestellen  
To be ordered when replacing the Bosch compressor  
A commander lors du remplacement du compresseur Bosch