






- 1) 41 8967—Der.
41 8968—Izq.
- 2) 18 6743
V01,V03
V05,V07
18 6744
V02,V04
V06,V08
- 3) 41 8969
V01,V03
V05,V07
18 6629
V02,V04
V06,V08
- 4) 41 9406
- 5) 21 8099
V01,V03
V05,V07
21 8101
V02,V04
V06,V08
- 6) 21 8096
V01,V03
V05,V07
21 8098
V02,V04
V06,V08


FSK44K26ED/01 – V01, blanco
 FSK44T26ED/01 – V02, beige
 FSK44K26ED/02 – V03, blanco
 FSK44T26ED/02 – V04, beige

FSK44K26ED/03 – V05, blanco
 FSK44T26ED/03 – V06, beige
 FSK44K26ED/04 – V07, blanco
 FSK44T26ED/04 – V08, beige

COCCIÓN
 Cocina a gas







- 1) 41 8540 (Peq.)
41 8541 (Gde.)
- 2) 48 2885–Del. Der.
- 3) 48 2886–Del. Izq.
- 4) 36 4749–Tras. Der.
- 5) 43 2231–Tras. Izq.
- 6) 43 2232–Cent. Del.
- 7) 43 2233–Cent. Tras.
- 8) 18 6663