





Gebrauchsanweisung
58 2416
(en,de,fr,it,es,pt,nl)

- 1) 18 3790
 - 2) 18 9609
 - 3) 18 9612
 - 4) 18 9685
 - 5) 42 2843
- V01, V03
41 6861
V02, V04



Düsensatz Für:
Flüssiggas 28 mbar
41 6319

Erdgas 20 mbar
41 6369

Flussigas 50 mbar
41 6687