





Gebrauchsanweisung
58 8654
(en,fr,it,de,es,pt,nl,tr)

- 1) 42 3495
V01
42 5219
V02,V03
2) 42 4525
3) 42 4526
4) 42 3527
V01,V02
42 5536
V03

Schlüssel für
Düsenwechsel
42 4699



- 1) 42 3501
V01,V02
42 5674
V03
- 2) 42 3509
V01,V02
42 5675
V03
- 3) 42 3544
V01,V02
42 5673
V03
- 4) 42 1964
- 5) 42 3531
V01,V02
49 4465
V03
- 6) 42 3530
V01,V02
49 4467
V03
- 7) 42 3533
V01,V02
49 4466
V03

Düsensatz für:
G-30, 50 mbar
42 1473
G-30, 30 mbar
42 4220
G-20, 20 mbar
42 4221
G-25, 25 mbar
42 4225
G-25, 20 mbar
42 4223