






51 2721
Gebrauchsanweisung
(D,GB,F,I,NL,E)

51 5436
Montageanleitung
(D,GB,F,I,NL,N,S,E)

08 4136
Schraubensatz

08 8957
Befestigungssatz





TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES					
Verdichter/Compressor/Compresseur		Matsushita			
Typ/Type		D116LRAA			
Forderleistung/Delivery/Débit		l/h	1184		
Anlaufstrom/Starting current/Cour. de démarrage		A	8,75		
Widerstand/Resistance/Résistance		Ha/main/prin.	Ω	12,0	
		Hi/aux	Ω	28,7	
Temp.-Regler/Thermostat		Ranco			
Typ/Type		K 59			
Reglerstellung/Position		kalt warm			
Schaltwerte/Switching values/		„ein“	°C	+ 4,5	+ 4,5
Valeurs de commutation		„aus“		- 31,0	- 13,5
(„abtauen“ od.)		„alarm“			
Füllmenge/Fill.quantity/Charge		R12	g	180	
Anschlußwert/Conn.load/Puiss. connectée		W	150		
Heizung/Heater/Chauffage					
Widerstand/Resistance/Résistance		Ω			
Leistung/Power/Puissance		W			
Ventilator/Blower/Ventilateur					
Widerstand/Resistance/Résistance		Ω			
Magnetventil/Magnetic valve/Electrovanne					
Widerstand/Resistance/Résistance		Ω			
Spannung/Voltage/Tension		V			

Pos.	Matsushita		
	D116LRAA		
1	14 0563		
2	05 8506		
3			
4			
5			
6	05 8458		
7	02 6731		
8	28 1825		
9	05 0166		
10	05 9467		
11	08 5182		
12	05 6008		