








Libro de instrucciones
(DE,GB,FR,IT,NL,SE,
FI,NO,PT,ES)
52 1375

- 1) 16 5720
- 2) 06 0637
- 3) 16 5727
- 4) 06 0472





TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS		
Verdichter/Compressor/Compresseur/Compresor	DANFOSS	
Typ/Type/Tipo	TL4F	
Förderleistung/Delivery/Debit/Aspiración l/h	695	
Anlaufstromm/Starting current/Cour.démarrage/Int.arranque A	3,2	
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm	17,1	
Hi/aux.	26,7	
Temp.Reyler/Thermostat/Termostato	DANFOSS	
Typ/Type/Tipo	077B4005	
Reglerstellung/Position/Conexión	MIN MAX.	
Schaltwerte/Switching values/ ..ein/conex.°C	-1,5° -10,5°	
Valeurs de commutation/Desconex. ..aus"/descon.	-22,5° -----	
(..abtaven' od) ..alarm'		
Füllmenge/Fill. quantily/Charge/Carga R134a g	40	
Anschlusswert/Comm. load/Puiss. Connect./Potenc. W	90	