





Gebrauchsanweisung
58 6065
(de,fr)


Zubehör:

Dampfgarer
N8640X2

Grillpfanne u. Bratrost
Z1230X2
Back,- u. Bratrost
Z1430X0
Bratenblech
Z1510X2
Backblech, Alu
Z1330X0
Backblech Email
Z1340X2
Brotbackstein
Z1910X0
Nachrüstatz Clou4/Kat.
Z1750X0
Auflaufform
Z1270X2
Nachruestsatz Clou
Z1740X0



1) 18 2294



- 1) 15 4762
- 2) 15 4763
- 3) 16 2920
- 4) 17 1615

