





Gebrauchsanweisung
58 3670
(en,pt,tr)



- 1) 18 4802
V01,V02
42 4754
V03
- 2) 18 4801
V01,V02
42 4758
V03
- 3) 18 4803
V01,V02
42 4756
V03

Düsensatz Für:
Flussigas 28 mbar
41 6319
Erdgas 20 mbar
18 7638