




Gebrauchsanweisung
52 3179
(D,GB,F,NL,I,E,GR)

1) 17 1322
2) 17 1323

Düsensätze:






Erdgas-E/H, G20
20mbar
17 1280

Erdgas-LL, G25
20mbar
17 1281

Flüssiggas (LPG)
G30/31-30/37mbar
17 1279

Flüssiggas G30/31
50 mbar
17 1252

Einbausatz
17 1337



1) 17 2273

