





Gebrauchsanweisung
58 2102 – V01,V02
(en,de,fr,it,es,pt,nl)
58 5568 – V03
(en,ko,)

- 1) 18 9685
V01,V03
V04,V06
41 6861
V02,V05
2) 18 9653
V01,V03
V04,V06
41 7667
V02,V05



1) 18 8360
2) 18 8361

Düsensatz Für:
Flussgas 28 mbar:
18 7479
Erdgas 20 mbar:
41 6374
Flussgas 50 mbar:
41 6687