



Burner Box Assembly



Page/Item	Part No.	Image	Part Description
01 01	369108	PLATE	SHIELD, HEAT-CTRL PNL LWR
01 02	487632	FRAME	TRIM, CONTROL PANEL LWR B
01 02	V01,V02, 487633	FRAME	TRIM, CONTROL PNL LWR SS
01 04	V03,V04,V05,V06, 487637	FRAME	TRIM, CTRL PNL MIDDLE BLK
01 04	V01,V02, 485707	FRAME	TRIM, CTRL PNL MIDL BRSH
01 06	V03,V04,V05,V06, 415457	CAP	ENDCAP, CONTROL PANEL LT
01 06	V01,V02, 415461	CAP	ENDCAP, CONTROL PANEL LT
01 06	V03,V04, 415459	CAP	ENDCAP, CONTROL PANEL LT
01 09	V05,V06, 415456	CAP	ENDCAP, CONTROL PANEL RT
01 09	V01,V02, 415460	CAP	ENDCAP, CONTROL PANEL RT
01 09	V03,V04, 415458	CAP	ENDCAP, CONTROL PANEL RT
01 12	V05,V06, 411358	WASHER	GROMMET, BLK
01 12	V01,V02,V03,V04, 411359	WASHER	GROMMET, WHT
01 14	V05,V06, 484749	GLASS PANEL	GLASS, CTRL PNL SEQ GAS B
01 14	V01,V02, 484751	GLASS PANEL	GLASS, CTRL PNL SEQ GRY
01 14	V03,V04, 484750	GLASS PANEL	GLASS, CTRL PNL SEQ GAS W
01 17	V05,V06, 487577	PLATE	PLATE, CNTRL MNTG 30" RNG
01 18	189969	SWITCH	SWITCH, LIGHT W/TERM
01 19	411226	LAMP	LIGHT, INDICATOR
01 20	486751	PUSH BUTTON SET	KIT-CONTROL BUTTON 30" RNG
01 21	486752	CONTROL UNIT	KIT-ERC III CONTROL (30" R
01 22	485768	BRACKET	BRACKET, VAC SWITCH
01 23	414635	REGULATOR-TEMPERATURE	THERMOSTAT, VAC
01 24	414634	REGULATOR-TEMPERATURE	THERMOSTAT, CV
01 25	411175	SPACER	SPACER, .250 OD x .596
01 28	368142	COVER	COVER, CTRL
01 29	367849	CLIP	CLIP, HOLD-DOWN
01 31	415571	BRACKET	BRACKET, SOLENOID
01 32	368112	BOX	BOX, BURNER 30" RNG-Q
01 33	484584	WASHER	GROMMET
01 34	368156	COVER	COVER, LATCH
01 35	368158	COVER	COVER, MODULE
01 36	486771	MODULE-POWER	SPARK MODULE KIT
01 37	411441	CONTROL MECHANISM	CONTROLLER, SIMMER
01 38	368125	COVER	COVER, SOLENOID & DR SW


RDFS30 FREE STANDING



Page/Item	Part No.	Image	Part Description
11 01	368110	PANEL–SIDE	SIDEWALL BLK
11 01	V01,V02, 142675	PANEL–SIDE	SIDEWALL S/S
11 01	V03,V04, 368111	PANEL–SIDE	SIDEWALL WHT
11 04	V05,V06, 485705	DUCT	DUCT, SIDE
11 05	414633	FUSE–THERMAL	HTC M2
11 06	415421	SWITCH	SWITCH, OVN LITE
11 07	368157	COVER	COVER, SIDE RT (GAS)
11 08	487674	LOCK–MECHANICAL	LATCH ASSY
11 09	411434	TUBE	TUBING ASSY (REGULAT–MANI
11 10	368159	COVER	COVER, SIDE
11 11	412939	AIR DUCT	VENT W/A, OVEN TOP
11 13	485716	AIR DUCT	VENT W/A, OVEN LWR (FS/SI
11 14	414191	LAMP	OVEN LAMP W/WIRE KIT
11 16	368153	DUCT	DUCT, CV AIR
11 18	189920	RELAY	RELAY, DBL LINE BREAK
11 19	411161	TERMINAL	BLOCK, TERMINAL
11 20	189034	REGULATOR–PRESSURE	REGULATOR, 5" W.C.
11 21	485678	TUBE	CONDUIT, FLEX 1/2 X 60
11 22	487570	COVER	COVER, TERMINAL BOX 30"RN
11 23	368124	COVER	COVER, RELAY
11 24	368129	BASE	BASE SD RAIL W/A SI/FS
11 25	415394	FOOT	FOOT, LEVELING
11 26	368131	COVER	COVER, BACK SLIDE–IN

* Not illustrated


Storage Drawer and Compartment



Page/Item	Part No.	Image	Part Description
13 01	487645	FRAME	TRIM, VENT FORWARD BLK
13 01	487646	FRAME	TRIM, VENT FORWARD WHT
13 03	487634	FRAME-DECOR	TRIM, BACKSPLASH FRONT BL
13 05	415462	CAP	ENDCAP, BACKSPLASH RT BLK
13 05	415465	CAP	ENDCAP, BACKSPLASH LT WHT
13 07	415463	CAP	ENDCAP, BACKSPLASH LT BLK
13 07	415464	CAP	ENDCAP, BACKSPLASH RT WHT
13 10	484738	GLASS PANEL	GLASS, BACKSPLASH PNL BLK
13 10	484739	GLASS PANEL	GLASS, BACKSPLASH PNL WHT
13 11	485700	STRIP	EXTRUSION, SILICONE 2.5FT
13 11	485701	STRIP	EXTRUSION, SILICONE 2.5FT
13 13	143245	COVER	COVER, BACKSPLASH
13 14	485726	PANEL	PANEL, BACKSPLASH
13 15	485732	BRACKET	BRACKET, SIDE TO SIDE
13 16	415760	PUSH BUTTON CAP	PUSH MECHANISM (DRAWER)
13 17	486749	RAIL	KIT-BASE RAIL 30"RANGE
13 18	369160	SLIDE	DRAWER SLIDE SET (FIXED&M
13 19	142664	DRAWER	DRAWER BODY P-PTD BLK 30"
13 20	238812	DRAWER	DRAWER ASSY, BLK 30"RANGE
13 20	238814	DRAWER	DRAWER ASSY, S/S 30"RANGE
13 20	238813	DRAWER	DRAWER ASSY, WHT 30"RANGE
13 23	142463	GLASS PANEL	GLASS, DRAWER BLK
13 23	142464	GLASS PANEL	GLASS, DRAWER WHT
13 25	412926	BRACKET	BRACKET, GLASS RETAINER B
13 25	412927	BRACKET	BRACKET, GLASS RETAINER W
* 40 01	SH-30/0064E		CIRCUIT DIAGRAM
* 40 02	SH-30/0065E		CIRCUIT DIAGRAM
* 50 01	RH30023E	REPAIR INSTRUCTION CGB36R	

* Not illustrated


Gas Maintop Component



Page/Item	Part No.	Image	Part Description
03 01	143060	GRATE	GRATE PACK BLACK (2 GRATE
03 01	488737	GRATE	GRATE W/FEET
03 03	189762	BURNER CAP	BURNER CAP ASSY "C" BLK G
03 03	189764	BURNER CAP	BURNER CAP ASSY "C" GLOSS
03 05	189766	BURNER CAP	BURNER CAP ASSY "B" BLK
03 05	189767	BURNER CAP	BURNER CAP ASSY "B" GLOSS
03 07	189321	TUBE	VENTURI 9 MM
03 08	189318	BASE	BURNER BASE "B"
03 09	189316	BASE	BURNER BASE "C"
03 10	189320	SEAL	O-RING "B" ISP#25-000-004
03 11	189317	SEAL	O-RING "C" ISP# 25-000-00
03 12	189324	IGNITION HEAD	IGNITION PLUG ASSEMBLY
03 13	142414	HOB TOP	MAINTOP, GAS BLK FS/SI 30
03 13	142418	HOB TOP	MAINTOP, GAS SS FS/SI RNG
03 13	142415	HOB TOP	MAINTOP, GAS WHT FS/SI RN
03 19	189322	RING	RING, MTG IGNITION PLUG

* Not illustrated


Manifold Assembly Sequence



Page/Item	Part No.	Image	Part Description
05 01	415015	CLAMP	CLAMP, SADDLE
05 02	413441	SCREW	SCREW,8–32x1.0 HEX WSHR H
05 03	368818	MANIFOLD	MANIFOLD W/A
05 04	485703	BRACKET	BRKT, BURNER 30" RNG–Q
05 05	188978	NUT	NUT,M22 X 1
05 06	411432	TUBE	TUBING ASSY LR S–B
05 07	484816	TUBE	TUBING ASSY LF V–S
05 08	411433	TUBE	TUBING ASSY LR V–S
05 09	484815	TUBE	TUBING ASSY LF S–B
05 10	484819	TUBE	TUBING ASSY RR V–B
05 11	411431	TUBE	TUBING ASSY RF V–B
05 12	411253	VALVE	SOLENOID
05 13	189315	HOLDER	JET HOLDER 11,000 ASSEMBL
05 14	414785	HOLDER	JET HOLDER W/NUT (9,100 G
05 15	188962	WASHER	WASHER, VALVE
05 16	412950	VALVE	VALVE 280 VIOLET
05 17	412949	VALVE	VALVE 280 (11K) RED
05 18	189984	VALVE	VALVE 210 (9.1K) BLUE
05 19	189983	VALVE	VALVE 210 (11K) ORANGE
05 20	189817	POTENTIOMETER	POTENTIOMETER
05 21	189008	SWITCH	SWITCH SPARK
05 22	411030	NUT	NUT, PUSH
05 23	415364	KNOB	KNOB, BURNER BLK
	V01,V02,V03,V04,		
05 23	415365	KNOB	KNOB, BURNER WHT
	V05,V06,		
* 05 31	413441	SCREW	SCREW,8–32x1.0 HEX WSHR H
* 05 32	415015	CLAMP	CLAMP, SADDLE
* 05 34	188962	WASHER	WASHER, VALVE

* Not illustrated


Main Oven Liner and Module



Page/Item	Part No.	Image	Part Description
07 01	485690	BRACKET	BRACKET, CONVECTION MOTOR
07 02	487099	MOTOR	MOTOR, CONVECTION
07 03	486916	BLAD	BLADE, MOTOR
07 04	142602	MOUNTING BRACKET	OVEN BACK MTG 30"OVN
07 05	368109	COVER	COVER, INSULATION 30"RNG
07 06	485770	PLATE	PLATE, HEAT BARRIER DI/FS
07 07	411220	catalyzer	CATALYST
07 08	414152	TEMPERATURE SENSOR	THERMAL SENSOR KIT
* 07 09	484494	CABLE HARNESS	HARNESS, THERMAL SENSOR
07 10	485563	PLATE	PLATE, COVER REAR/SHIELD
07 11	484639	INSULATING PART	INSULATION, CONVECTION MT
07 12	238652	OVEN	CAN, OVN 30" W/A PORC
07 13	485564	PAN	PAN, REAR CONVECTION
07 14	486202	FAN BLADE	BLADE, CONVECTION RH R/A
07 15	485565	COVER	COVER, CONVECT FAN FRONT
07 16	367555	INSULATING PART	INSULATION, 2" OVN WRAP 1
07 17	485717	DEFLECTOR	DEFLECTOR, HEAT-BROIL
07 18	367645	HEATER-ELEMENT	ELEMENT, OVN BROIL
07 19	238661	PANEL	OVEN MODULE BODY 30"(CT/R
07 20	484627	GRID	GRIDDLE, BROIL
07 21	484628	PAN	PAN, BROIL
07 22	414510	HOLDER	SUPPORT, HINGE COUNTER
07 23	368822	SHELF	RACK, OVEN PLATED GE
07 24	367646	HEATER-ELEMENT	ELEMENT, BAKE
07 25	368100	FRAME	FRAME, FRONT TOP RNQ
07 26	415421	SWITCH	SWITCH, OVN LITE
07 27	485696	FRAME	FRAME, FRONT BTM

* Not illustrated

Main Oven Door Assembly



Page/Item	Part No.	Image	Part Description
09 01	238676	DOOR	DOOR ASSY BLK 30" RNG-Q
09 01	V01,V02, 142669	DOOR	DOOR ASSY S/S 30" RNG-Q
09 01	V03,V04, 142668	DOOR	DOOR ASSY WHT 30" RNG-Q
* 09 04	V05,V06, 484640	INSULATING PART	INSULATION, DOOR SIDE
09 05	367561	INSULATING PART	INSULATION, DOOR BTM
* 09 06	367560	INSULATING PART	INSULATION, DOOR TOP
09 07	414541	SEAL-DOOR	GASKET, DOOR 65"
09 08	486917	HINGE	HINGE, DOOR
09 09	413386	CLIP	CLIP, WINDOW PACK
09 10	412883	SEALING KIT	KIT-GASKET 36 INCHES
09 11	369151	SPACER	SPACER, INNER WINDOW/FRAM
09 12	486968	GLASS PANEL	GLASS, INNER DBL COAT 18x
09 13	368109	COVER	COVER, INSULATION 30" RNG
09 14	484796	BRACKET	BRKT, DOOR BTM
09 15	485697	AIR CHANNEL	BAFFLE, AIR
09 16	412936	SUPPORT	DOOR GLS SUPPORT TOP W/TA
09 17	485718	SUPPORT	SUPPORT, DOOR GLS SIDE LT
09 17	V01,V02, 485720	SUPPORT	SUPPORT, DOOR GLS SIDE LT
09 17	V03,V04, 485719	SUPPORT	SUPPORT, DOOR GLS SIDE LT
09 20	V05,V06, 485721	SUPPORT	SUPPORT, DOOR GLS SIDE RT
09 20	V01,V02, 485723	SUPPORT	SUPPORT, DOOR GLS SIDE RT
09 20	V03,V04, 485722	SUPPORT	SUPPORT, DOOR GLS SIDE RT
09 23	V05,V06, 412929	ADHESIVE TAPE	TAPE, FOAM .125thkx.500wdx
09 24	143004	GLASS PANEL	KIT-DOOR GLASS 30" RANGE B
09 24	V01,V02,V03,V04, 143003	GLASS PANEL	KIT-DOOR GLASS 30" RANGE W
09 26	V05,V06, 415366	SPACER	SPACER, HANDLE
09 27	412926	BRACKET	BRACKET, GLASS RETAINER B
09 27	V01,V02, 414187	BRACKET	KIT-DOOR GLASS 30" RANGE S
09 27	V03,V04, 412927	BRACKET	BRACKET, GLASS RETAINER W
09 30	V05,V06, 487592	HANDLE	HANDLE, OVEN BLK
09 30	V01,V02,V03,V04, 487593	HANDLE	HANDLE, OVEN WHT
	V05,V06,		