




Gebrauchsanweisung
51 7958
(D,GB,F,NL,I,E,GR)

Montageanleitung
51 7955
(D,GB,F,NL,I,E,GR)

Tips und Rezepte
51 8100
(D)

Zubehör:

Grillpfanne u. Bratrost
Z1230X0

Backblech, Alu
Z1330X0


Backblech Email
Z1340X0

Bratrost gekröpft
Z1430X0


Bratrost engmaschig
Z1440X0


Adapter MEGA
Z9600X0

1)02 5876



- 1) 15 4749
V01,V04
15 4792
V02,V05
15 4789
V03,V06
- 2) 15 4748
V01,V04
15 4791
V02,V05
15 4788
V03,V06





1) 15 5033