





Gebrauchsanweisung
58 3670
(en,pt,tr)



- 1) 18 8350
V01,V02
42 6941
V03
- 2) 18 8349
V01,V02
42 6940
V03
- 3) 18 8348
V01,V02
42 6939
V03

Düsensatz Für:
Flussgas 28 mbar
41 6319
Erdgas 20 mbar
18 7638